


"Best" Echo Chambers Featuring Easy-to-operate Design and Well-developed Mechanism

Roland Echo Chambers RE-101/RE-201



Deepen the Depth of Your Music

Practical 3-channel Input Control

The RE-101 and RE-201 are equipped with independent three channel input controls—two for microphones and one for instruments—and produce high quality sounds when these inputs are mixed using level meter and peak level pilot lamp. Also, in instrument channel, echo effect on instrument sound can be canceled with the echo/normal changeover switch. This is convenient when a microphone is used with instruments.

Rich Variation of Echo Sounds

The RE-101 provides 6 modes of echo sounds and the RE-201, 12 modes including reverb effect. These modes are further varied by the repeat rate, intensity and echo volume controls for rich echo sound variation. In the RE-201, echo sound tone can be freely adjusted by the treble and bass controls without influencing

original sound. The RE-201 incorporates a reverb unit made by the O.C.E. in U.S.A. to add clear reverberation effect to echo effect.

Well-developed Mechanism with Minimal Wow & Flutter and Low Noise

Free running system (tape runs freely in the case and appropriate length and rotation of endless tape are maintained) is employed for tape running unit. Newly-engineered heads and running unit, direct drive type brushless electronic servo motor, and quality endless tape "RT-1" keep wow and flutter and noise at a minimum. Thus best echo sound is always obtainable. Furthermore, tape life is greatly prolonged to 400 hours, 10 to 20 fold, compared with conventional echo chambers, and during this time, quality of the tape is maintained.

RE-101

Standard Model with RE series standard functions

Mode Selector

6 modes of echo effect can be selected.

Playback head activated by mode selector							
Mode		REPEAT			SWELL		
		1	2	3	4	5	6
Playback Heads	1	•					
	2		•				
	3			•			

Repeat Rate

Intensity

Echo Volume

Level Meter



RE-201

Initiative model with built-in reverb control and echo tone control

Peak Level Pilot Lamp

This lamp indicates the peak of shock sound from such sounds as electric guitar in which the attack time is rapid and cannot be detected by meter. By this, exact input level adjustment is obtained.

Level Meter

Accurately indicates the input level. This level meter is interlocked with foot switch; on and off of echo effect can be seen since lamp comes on or goes off with the ON/OFF control of the foot switch.

Mic Volume

Instrument Volume

Mic and instrument volume input level controls make it possible to use two microphones and one instrument at one time. Levels can be set while mixing, with less distortion and noise.

Mic Input

Instrument Input

Mode Selector

12 rich modes are available: 4 modes for echo effect, 7 for combined use of echo and reverb and 1 for reverb only.

Playback head and reverb activated by mode selector											
Model		REPEAT				REVERB ECHO				REVERB ONLY	
		1	2	3	4	5	6	7	8	9	10
Playback Heads	1	•				•					
	2		•				•				
	3			•				•			
Reverb						•	•	•	•	•	•

Bass Treble

Echo Tone Control

Bass and treble of echo sound can be controlled without impeding original sound for producing echo tone that fits your needs.

Reverb Volume

Depth of reverb effect can be freely controlled. The 3 spring type reverb unit made by the O.C.E. in U.S.A. produces clear reverb sound.

Repeat Rate

This controls the interval of echo sound from short to long for varying echo effect set by mode selector.

Intensity

Length of echo effect can be freely set by this control. Maximum value of echo effect length can also be ascertained by the oscillation phenomenon.

Echo Volume

Controls the volume of echo sound. Balancing echo sound and original sound is achieved by this control.



Echo/Normal Changeover Switch

ON/OFF control of echo effect on the instrument connected to the instrument channel is easily controlled by a flip of finger.

From P.A. Input

Input for P.A. mixer or vocal mixer.

Output

With provided 3-step output level change switch, suitable output can be selected according to the amp or mixer to be connected.



Foot Switch Jack

ON/OFF control of echo effect or reverb effect can be done with the foot switch. Also, the foot switch is interlocked with level meter lamp, and ON/OFF of echo effect can be visually ascertained by the lamp illumination.

●RE Series Specifications

Model		RE-101	RE-201
Channel		3	3
Input	Microphone	2	2
	Instrument	1	1
	From PA	1	1
Output		1	1
Output level change switch		1 (H/M/L)	1 (H/M/L)
Foot switch jack		1	1
Control	Mode selector	1 (Rotary type 6-mode)	1 (Rotary type 12-mode)
	Repeat rate	1	1
	Intensity	1	1
	Echo volume	1	1
	Tone		1
			1
	Reverb volume		1
Level meter		1	1
Peak level pilot lamp			1
Instrument channel Echo/Normal changeover switch		1	1
Power switch		1	1
Erasing head		1 (Full track 2 channel)	1 (Full track 2 channel)
Recording head		1 (Full track 2 channel)	1 (Full track 2 channel)
Playback head		3 (Full track 2 channel)	3 (Full track 2 channel)
Motor		Electronic servo direct drive	Electronic servo direct drive
Consumption power		14 W	14 W
Outer dimensions		415(W)x275(D)x185(H)mm(16.3"x10.8"x7.3")	415(W)x275(D)x185(H)mm(16.3"x10.8"x7.3")
Weight		9.2 kg or 20.3 lbs.	9.5 kg or 20.9 lbs.
Accessories		Connection cord x 2, foot switch (FS-1), endless tape (RT-1), cleaner, vinyl cover	Connection cord x 2, foot switch (FS-1), endless tape (RT-1), cleaner, vinyl cover

●Connection



●Cartridge tape RT-1



Always use RT-1 to get quality tone.



Roland